

SandDevil

Changing and Repositioning the Sanding Belt

Step 1

Simply lift lever.



Step 2

Rotate or change sanding belt.



Step 3

Easily push to lock lever and secure belt.

